

OMNOVA Solutions

Wallcovering Reclamation Program Checklist

Materials for the OMNOVA Solutions wallcovering reclamation program must be prepared and packaged properly. Complying with these instructions is important to facilitate the proper processing and recycling of the wallcovering.

Inspect wallcovering

- Check to ensure product is fabric backed vinyl wallcovering or OMNOVA wallcovering with **ECORE™** Advanced Wall Technology.
- Inspect materials and discard any with mold or mildew. They cannot be used and must be disposed of in a landfill.
- Remove all nails, staples, screws and foreign materials, paying close attention for any items containing metal.
- Send only dry material.
- Installation trim, scrap and unused wallcovering can be included in the shipment for recycling.

Packaging and shipping

- Remove wallcovering from wall (approximately 8 foot lengths).
- Stack 6-10 sheets on top of each other and roll the sheets.
- Place in OMNOVA-provided plastic bags or other packaging and seal with bag ties. For large returns, please contact OMNOVA Customer Service for alternative packaging.
- Affix shipping label to each bag.
- Ship materials.

For additional information, please contact OMNOVA Customer Service at:

Wallcovering Reclamation Program
133 Yorkville Rd. East
Columbus, MS 39702
Phone: 800-457-9900
E-mail: reclamation@omnova.com



OMNOVA Solutions Inc. • Fairlawn, OH 44333 • www.omnova.com
reclamation@omnova.com

ECORE is a trademark of OMNOVA Solutions Inc.
© 2008 OMNOVA Solutions Inc. 10/08